



SKU # 597 341

Model # TY084-1118-1C

USE AND CARE GUIDE

4-Piece 18in Spiral Tree Pathway Lights



THANK YOU

We appreciate the trust and confidence you have placed in Home Accents through the purchase of this 4-Piece 18in Spiral Tree Pathway Lights. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Accents!

Guarantee

What is Covered

The product is intended for residential seasonal use for approximately 90 days per year. This product is covered by a 90 day limited guarantee due to defects in material and workmanship. Return the product with purchase receipt to the location of purchase for refund within 90 days of purchase.

What is Not Covered

This warranty does not cover commercial use, normal wear and tear, products not used in accordance with directions provided on or with the product, burn out of bulbs or LEDs, batteries, products that have been subjected to unauthorized repair and/or modification and damage caused by shipping and improper handling, alterations, misuse or accidents. Questions, problems, missing parts? Before returning to the store, call Home Accents Holiday Customer Service 8 a.m.-6 p.m., EST, Monday-Friday

1-877-527-0313


HOMEACCENTSHOLIDAY.COM

Pre-Assembly

PLANNING ASSEMBLY

Carefully remove all the parts from the box and place them on a flat surface. Read the entire manual prior to assembly and identify all the parts included in the package against the parts list. If any parts are missing or damaged do not attempt assembly. Contact our customer service center or return to store. Assembly of this product may require more than one person.

PACKAGE CONTENTS



Package Contents/Parts List		
Part	Description	Quantity
A	Star Tree Topper	4
B	Spiral Tree	4
C	Driving Cap	4
D	Plastic Cap	4
E	Pole Section	4
F	Tree Stand	4
G	Fuse	2
H	Replacement Bulbs	6

Assembly

Assembling the Spiral Tree



Fig. 1




Fig. 2

For Indoor Use:

- (1) Place the Tree Stand (F) flat on the floor. Fig.1
- (2) The Tree Stand has a short vertical stub projecting upwards from it. Insert one Pole Section(E), with big the end down, into the vertical stub. Attached the Plastic Cap (D)to the top of the Pole Section . Fig.1
- (3) Hold the Spiral Tree (B)at the top of the Pole section. Insert the Pole Section into the disc at the top of the Spiral Tree. Let the Spiral Tree uncoil over the Pole Section (E).Fig.2
- (4) Place the Star Tree Topper(A) into the holder at the top of the Spiral Tree. Fig.2
- (5) Attach the hooks at the end of the two supporting strings at the base of the Spiral Tree into the metal holes on the stand. Fig.2




Fig.3

For Outdoor Use:

- (1) One of the arms of the Tree Stand is tapered. Drive the sharp arm of the Tree Stand into the ground using the Driving (C) on the opposite end of the Tree Stand, as shown in. Fig. 3
- (2) Repeat Steps 2-5 from Indoor Use above. (Note: Be sure to remove Driving Cap)

Pre-Operation

CAUTION: Grasp the plug to insert or remove from the power source. Do not unplug by pulling on cord.

CAUTION: The lighting string on this product is rated at 57.6 Watts (0.48Amps). Do not overload. Do not connect to other lighting strings, decorative outfit or other electrical products. Before you use or re-use this product inspect it carefully. Return to Store or discard if the product has cuts, damage or frayed wire insulation on cords, cracks in the socket enclosures, loose connections or exposed copper wire.

Care and Cleaning

- a. Carefully remove the product from wherever it is placed. This helps to avoid any undue strain or stress on the product, wire and lighting connections. If the product is placed somewhere other than the ground it should be well secured and stable.
- b. Wipe the unit with a damp cloth and allow the unit to dry before storing.
- c. Store the product neatly in a cool, dry location protected from sunlight.

FOR INDOOR AND OUTDOOR USE